

www.gpsgolfbuddy.com

Advance Operations

Green View Screen

First, change the screen to the distance information view by pressing the [P] and [+] button simultaneously. Pressing the [C] button gives you the green view screen. The green shape changes as you move to the different sides of the green. The screen also provides the hole number, par information, and left/right green information.



1. 08 Hole No.
2. [C] Green View
3. P4 Par Information
4. L Left Green R Right Green


Measuring Distance

Press the [P] button then press and hold the [C] button for 3 seconds to start measuring. Once you have arrived at the desired location, press the [P] button to finish measuring and you can view the measured distance.




Changing Holes

Press both the [C] button and the [+] buttons at the same time to bring up the hole selection. Then use the [C] [P] button to change to the desired hole.



Time Setting

Press and hold the [P] button to see the current time. Press and hold the [C] button to set the time.



Flipped Screen Mode

Press and hold the [P] and [-] buttons simultaneously, the display rotates upside down. It's for the user convenience, when a player wants to see the screen while wearing it on his belt, without pulling it off.



What's included



GolfBuddy Voice+



Power Adaptor



USB Data Cable



Silicon Case



Quick Start Guide



Wrist Band

GolfBuddy
VOICE+

Quick Start Guide

GolfBuddy VOICE+




Thank you for choosing GolfBuddy.
GolfBuddy Voice+ provides golf course information for you to ensure you enjoy the very best golfing experience.

Quick Overview of your GolfBuddy



Screen Description



Getting Started

Plug the data cable to the power adapter to charge the unit. Visit our website (www.gpsgolfbuddy.com) and check your course in our "course library" and download if necessary. Please refer to the GB manager for the latest course and firmware updates.

Basic Operations

Power On/Off

Once you're at the course, simply power on to start playing as the unit will locate your course for you automatically.



Language Selection

Have the unit turned off. While holding down the **ESC** button, turn on the unit to bring up the language selection. Use the **Left** and **Right** buttons to select your language.



Voice Information of the Distance to the Green

Pressing the **ESC** button will give you the distance to the center of the green. Press and hold **ESC** button will give you the distance to the front and back of the green.



Press and hold the **P** and **ESC** button simultaneously, the screen changes to the distance information view.



Press **ESC** button once : Voice information to the center.
Press and hold **ESC** button : Voice information to the front.
Press and hold **ESC** button again : Voice information to the back.

Switching to the Alternate Green



Press and hold the **Left** button while on the play screen.

Changing the Distance Unit (Yard/Meter)



Press and hold the **Right** button while on the play screen.

Volume Control



Use the **Left** and **Right** buttons to control the volume.

Mute



Press the **Left** and **Right** buttons at the same time to mute.