



8 POINT TRUNDLER CHECKLIST

SAFE USE OF YOUR ELECTRIC TRUNDLER


Your trundler is designed for the transportation of golf bags and clubs.

1. Do not attempt to transport any other equipment
2. Do not use the trundler to assist you when going up hills
3. Submerging the trundler in water (eg. a lake) is likely to cause serious damage to the trundler
4. Do not leave your trundler unattended with the battery plugged in - apart from when on the golf course.
5. Do not connect another battery to trundler without first checking for correct battery polarity.
6. All batteries must be disconnected from the trundler before transporting
7. Lead acid batteries must be removed from the battery tray before transporting your trundler
8. Always use the carry strap when moving and transporting lead acid batteries

CARING FOR YOUR TRUNDLER

Although your trundler has been weatherproofed (they are not waterproof), please follow these simple guidelines to help protect your trundler:

- Do not store your trundler outside
- Try to minimise exposure to rain as much as possible with an umbrella during heavy rainfall
- Wipe excess water from the trundler prior to storage
- If playing in heavy rain, consider keeping a plastic bag and rubber band in your golf bag to wrap around the top handle
- Bi-monthly spray a bit CRC or WD40 into the clutch/ bearings of each rear wheel.
- Never use a pressure washer or garden hose to clean your trundler. To prevent water damage, wipe it down with a damp cloth
- Avoid using high pressure air hoses near moving components



Your trundler is designed to require very little maintenance; we do however recommend giving your trundler regular checks to ensure:

- There is no buildup of excess mud and dirt
- The front wheel nut is on tightly and quick release lever is clamped down
- The front wheel is not clogged up and turns freely
- The battery bag and strap are intact and not damaged (lead acid batteries only)
- We recommend getting an annual service done on your trundler in order for it to remain reliable.

CARING FOR YOUR LITHIUM BATTERY

- When you first purchase your trundler put the battery on charge immediately prior to your first round.
- Try to avoid getting the battery too wet (i.e. do not submerge the battery, try to avoid deep puddles and do not clean your trundler whilst battery is still in the battery tray)
- Dropping the battery may cause damage to the internal cells
- Do not lift or carry the battery by the cable
- Use a damp cloth to clean off any dirt

If for any reason your lithium battery is not going to be used for lengthy periods, e.g. 3 months over the winter, it is advised to store the battery half charged. To do this simply use the battery for a round of golf as usual and charge it for 1.5 hours at the end of the round. Before the battery is used again, recharge it (top it up) prior to use. We recognise that extended absences are not always planned in advance, however when it is likely that you will not be using your battery for a period of time it is good practice to follow these steps to extend the life of your lithium battery. Please ensure that the charger is ALWAYS disconnected from the battery after charging.

WARRANTY COVER

Please note the manufacturers warranty covers faulty parts and workmanship for the period as specified by the brand you have purchased. However this warranty does NOT cover you for misuse, abuse, wear and tear, or neglect of your trundler or battery.